

Pergo Vinyl Sunsafe Underlay**Description:**

- Developed for use in situations with high temperature variations (e.g. conservatory).
- Suitable for installation under vinyl click floors.
- Easy installation.
- Perfect for floor heating/cooling.
- Reduces reflected walking sound and transmission sound.

Characteristics:

Product code	PGVUDLSS10	
Colour	Red/white	
Shape	Roll	
Thickness	1.5 mm	EN 823
Length	10.000 mm	EN 822
Width	1000 mm	EN 822
Compression strength	400 kPa	EN 826
Fire protection classification	B _{fl-s1}	EN 13501 – 1
Thermal conduction resistance	0.01 m ² K/W	DIN 4108
Impact sound insulation	ΔL _w = 15dB	IHD 431
Walking noise reduction	-20%	

Installation instructions:

1. Unfold the underlay on the subfloor. Lay the underlay strips parallel to the laying direction of your Pergo® floor with the Pergo® logo on the top side. Do this strip by strip, as the laying of your floor progresses.
3. Install the following row next to the first. Seal the joints between the underlay with a damp-proof tape in order to keep the underlay in place.
4. Make sure the underlay fits together tightly (don't leave any gaps).

Pergo Vinyl Sunsafe Underlay

5. The VINYL Sunsafe underlay has best performance when it is used on a “perfectly” smooth and dry subfloor. When required a levelling should be applied to make the subfloor smooth.

