

This installation guide gives you a summary of the most important points to consider before, during and after installation. For more detailed written guidance and tutorial videos, we recommend that you click/scan the QR-codes in this guide. If you are unable to check the website or scan the QR-code, please contact your dealer or contact your local Unilin technical services.

TO OBTAIN THE BEST RESULT, THE INSTALLATION GUIDE MUST BE CAREFULLY FOLLOWED BY ALL PARTIES.  
LOCAL REGULATIONS AND STANDARDS REGARDING INSTALLATION OR SITE CONDITIONS MUST BE FOLLOWED IF THEY ARE STRICTER.

### SUITABILITY, CARE, MAINTENANCE AND WARRANTY GUIDELINES



MAINTENANCE



REPAIR GUIDE



WARRANTY



FLOOR HEATING

- Designed for indoor heated applications, see condition table.
- Aquasafe technology allows installation in humid areas (for specific water-resistant conditions, see warranty).
- Not suitable in areas which have a built-in floor drain.
- Not suitable in very humid/dry areas or in areas where the flooring may occasionally be exposed to extremely high or low temperatures (such as but not limited to solariums, seasonal porches, saunas, non-heated rooms, pool areas and shower floors, etc.).
- A floating installation should remain floating! Never fix/block/permanently load a floating floor! (e.g. do not install kitchen, built-in closets, heavy stoves, fixed objects,... on top of the floor).
- Boxes should be stored and transported flat, in neat stacks. Never store them upright.
- For maintenance instructions: click/scan the Maintenance QR-code.
- Preventive measures:
  - Install a proper doormat at all external entrances;
  - Contact with rubber may cause discoloration;
  - Keep the furniture legs always equipped with soft and clean protective pads;
  - Use soft castor wheels (type W according to EN 12529) and/or a suitable protective mat
  - Never drag items over the floor, but lift them.
- Remove spills immediately.
- In case of damage, click/scan the Repair guide QR-code.
- Sunlight might affect the original color. This may lead to color fading and color changes.
- Temperature variations can cause open joints, see warranty.
- For more information about the warranty (residential and commercial applications): click/scan the Warranty QR-code.
- In case of floor heating /cooling: click/scan the Floor heating QR-code.

| CONDITIONS TABLE                                                                                                            | AMBIENT ROOM- AND FLOOR TEMPERATURE                                                                                                                      |
|-----------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Storage & transport                                                                                                         | 0-35°C   no damp areas                                                                                                                                   |
| Acclimatization + during installation<br>Floating installation: 48 hours before, during, until 24 hours after installation. | 15-25°C                                                                                                                                                  |
| Usage                                                                                                                       | 8x8m: temperature is guaranteed between 0-65°C<br>13x13m: temperature is guaranteed between 15-35°C<br>30x30m: temperature is guaranteed between 18-25°C |


In case of floor heating/cooling, see floorheating instructions.

# Installation Guide

## RIGID CLICK VINYL

**PERGO**  
Floors for real life

### PREPARATION



UNDERLAY



SUBFLOOR  
GUIDANCE




UNDERCUTTING  
DOORFRAME

- Acclimatize the unopened boxes on a flat surface in the area of installation or one with equivalent conditions, see conditions table
- An installed panel/floor is considered as an accepted panel/floor; installation implies acceptance! Ensure that the materials codes and appearance match the selected/ordered floor and always check the product for:
  - damage or defect;
  - appearance in optimal light conditions (e.g. colours, gloss variation).
- Keep at least:
  - one box-label;
  - your purchase receipt;
  - photo of all codes on the underside of 1 panel.
- We highly recommend to keep some spare panels for replacements in case of damage to the floor during its lifetime.
- All works that have influences on the RH% in the room (e.g. plasterworks) should be completed and dried out beforehand.
- The type of subfloor, its quality and its preparation significantly affect the final result.
- For detailed subfloor guidance: click/scan the Subfloor guidance QR-code.
- Remove existing and/or too soft floorcoverings (like carpet, needle felt, cushion vinyl, ...). Floating floor coverings must also be removed.
- The subfloor must be solid, self-supporting, stable, structurally sound, flat, clean and permanently dry, as well as being free from irregularities or defects and fit for the purpose intended.
- Moisture content of the subfloor (if the subfloor moisture content exceeds the recommended levels, consult subfloor material manufacturers for suitable damp proofing and preparation):

| SUBFLOOR                     | UNHEATED                   | HEATED*           |
|------------------------------|----------------------------|-------------------|
| Cement                       | < 2.5CM% - 75% RH          | < 1.5CM% - 65% RH |
| Anhydrite (Calcium sulphate) | < 0.5CM% - 75% RH          | < 0.3CM% - 65% RH |
| Wood based                   | < 10%MC (moisture content) |                   |

\*Start the floor heating at least two weeks before laying your Pergo floor, see Unilin floor heating instruction and floor heating instruction of the manufacturer.

- Flatness of the subfloor:



If irregularities exceed these limits, sand the surface and/or use a smoothing compound.

- Monitor and keep records of your measurements (e.g. subfloor moisture content, RH, room temperature readings,...).
- For Pergo Vinyl floors with underlay attached, AN ADDITIONAL UNDERLAY IS NOT ALLOWED! To choose the correct underlay for vinyl floors without underlay attached: click/scan the Underlay QR-code.
- Required tools: ruler, pencil, hammer, saw, square, suitable dust mask, safety gloves and goggles, Pergo vinyl cutter knife, string/chalk line, tapping block, pull bar and spacers.
- Undercutting doorframe: click/scan Undercutting doorframe QR code.


### GENERAL INSTALLATION RULES

- The temperature will influence the properties of the material, see conditions table.
- Transfer the subfloor joints to the surface of the floorcovering when you have a risk of movement of the subfloor.
- Maintain the correct expansion gap:

| TYPE OF INSTALLATION | INSTALLATION SIZE                                                                                                                                                                                                                                     | EXPANSION GAP REQUIRED                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Floating             | <ul style="list-style-type: none"> <li>• For standard residential use (15-35°C): max 13x13m</li> <li>• For rooms with more extreme temperatures (0-65°C): max 8x8m</li> <li>• For rooms with permanently HVAC-system (18-25°C): max 30x30m</li> </ul> | <ul style="list-style-type: none"> <li>• 8 mm</li> <li>Expansion gaps are mandatory on the entire perimeter of the floor, around all fixed and/or possible blocking objects, pipes, ....</li> <li>• Intermediate T-profiles are mandatory when 1 or more of the following apply (respect the expansion gap on either side of the profile): <ul style="list-style-type: none"> <li>• Temperature in adjacent rooms or irregular shaped rooms (e.g. L, U, T-shaped rooms) will be outside of the temperature range 15-25°C.</li> <li>• There is floor heating/cooling and there are different heating temperatures zones.</li> <li>• Maximum installation size is exceeded.</li> </ul> </li> </ul> |


- The base of the doorframe must not create a fix point to the floor.
- Remove all spacers within 24 hours.

### HOW TO INSTALL?




1. Choose the floor direction.
2. Install your Pergo underlay in the same direction as the length of the panels. Add additional underlay rows as you proceed with the installation of the panels. You can find more information on how to install the Pergo underlay on the technical data sheet of the underlay or at your dealer.  
FOR Pergo VINYL FLOORS WITH UNDERLAY ATTACHED, AN ADDITIONAL UNDERLAY IS NOT ALLOWED!
3. Check how many full rows of panels you will need by dividing the width of the room by the width of a panel.
4. Mark reference points on the wall where you'll be laying your first full row (row #2). The width of the first and last row should be at least 5 cm.  
Mark a reference line on the subfloor between the reference points on the wall.
5. Unpack your panels from multiple boxes and mix them up to avoid adjacent identical patterns and colours.
6. We recommend a random installation.
7. The length of the first and last panel of a row should be more than 20 cm. Make sure to alternate your alignment so that end joints of panels in adjacent rows are never in line. There must be at least 30 cm between them.  
For small tile format: there must be at least 20 cm between them.
8. To obtain a clean cut to shorten the length of the panel, the top layer of the panel must be upwards when you use a vinyl cutting knife. You do not need to completely cut through the vinyl, score the surface only. Then break off the panel by using both hands.  
For other cuts, you may need a saw. Depending on the type of saw and blade, the top layer of the panel must be upwards or downwards to obtain a clean cut. (Test with a leftover piece to get the best cut finishing).

9. Click system:  
Uniclick click system




- Method A (angle-angle) is the preferred way of installing: Rotate the short side of the panel to be installed, into the short side of the already installed panel, by means of the angle principle. Then raise the newly installed panel to an angle of 20-30° by sliding the fingers of both hands under the raised length edge of the panel, close to the short end joint. Grip the panel and pull the panel towards you. The panels will now click together. You can either insert the tongue into the groove, or the groove into the tongue. The tongue into the groove method is the most common and easiest way.  
Tip: Lay some weight on top of the newly installed row to help prevent the entire row from unlocking while you continue installation.
- Method B: By using the Uniclick tapping block, you can gradually tap the panels into each other without lifting. Only use method B if method A is not possible.
- In places where it is too difficult to install the Uniclick panels with the tapping block (e.g. last element in the row against the wall), you can tap them together using the pulling iron and a hammer.




- Install the first 2 rows (rows #2 and #3) away from the wall (as walls are hardly ever perfectly straight) and cut end pieces to required size.  
Align your rows to the reference points on the wall and the subfloor/underlay. Install panels one by one alternately in rows #2 and #3, so every panel has the short and long side locked before you install the next one (don't lock only the short side).
- When installing your row (row #1) against the wall, always saw off your click profile and be sure that you will cut the panel in order to follow the shape of the wall. Put spacers between the panels and the wall to ensure the correct expansion gaps.
- Complete the rest of the installation by using method A and method B.

### EXTRA NOTIFICATION FOR HERRINGBONE:



1. Choose the floor direction.
2. We recommend ensuring that all pieces of the floor are always bigger than 100 mm. If it is not possible to assure this, use soft PVC glue to connect these pieces to the adjacent floor panels.  
Mark reference points on the wall and a reference line on the subfloor to center your floor = start line.
3. To obtain a clean cut to shorten the length of the panel, the top layer of the panel must be upwards when you use a vinyl cutting knife. You do not need to completely cut through the vinyl, score the surface only. Then break off the panel by using both hands.  
For other cuts, you may need a saw. Depending on the type of saw and blade, the top layer of the panel must be upwards or downwards to obtain a clean cut. (Test with a leftover piece to get the best cut finishing).
4. The first part of the installation consists of assembling the center rows. You can do this by assembling the first 3 panels, labeled as "1", "2" and "3". Panel "3" is used as a helping hand to align panels "1" and "2". Always keep your long side tongue of the panels in the same direction.  
Connect panels "1" and "3" (at a slight angle of 20 to 30° insert the longside panel 3 into the longside panel 1), the short edge of panel "3" must be 5 mm beyond the short edge of panel "1". Now insert the longside of panel "2" in the shortside of panel "1". Slide panel "2" until it is stopped by panel "3". Now fold down panel 2.
5. Now install panel "4", which is taking over the role of panel "3". Uplift panel 3 at an angle of 20 to 30° and slide it upwards until it touches panel "4". Follow this method until you finished the first, center V-row of your floor. Always work in the direction of the arrows of the pictograms.
6. Make sure that this V-row is aligned with the start line.
7. Unizip:



METHOD A

METHOD B

- Method A (angle-angle) is the preferred way of installing: Install the short side of the panel to be installed, into the long side of the already installed panel in the previous row, by means of the angle principle. Then raise the newly installed panel to an angle of 20-30°. Grab the long side of your panel with your both hands close to the short side and pull the panel to lock the long side. The panels will now click together. When necessary, you can use a Pergo tapping block to close fine gaps.
- Method B (optional): Install the first panel of the new row. Install the long side of the new panel into the long side of the previous panel. While holding the new panel in an angle of 20 to 30°, slide this panel until its short end reaches the installed V row. Now you can drop down the panel, followed by gently tapping the panel on its short end until it locks into the installed V-row. Tapping must always be done with a hammer and a suitable tapping block in the direction of the central V-row.
- 8. You can continue to install the additional rows of full panels. To install the next row, we recommend using method A. For each row, always keep your long side tongue of the panels in the same direction. Always control each joint before continuing.
- 9. For the finishing / side / end cut panels:
  - When the wall is parallel to the V-row: rotate your panel by 180°. Place the corner against the wall minus the distance of the spacer. You now can draw the cutting line and cut off the surplus. Turn back the panel 180° and install it. Repeat this with each individual panel.
  - When your wall is not parallel to the V-row, measure the lengths A-A' and B-B'. Transfer these measurements onto the panel you want to install.

## FINISHING



### STANDARD:

- Attach the skirtings to the wall (never to the floor).
- Do not fill expansion gaps (except with Foamstrip covered with Pergo Aqua Sealant).

### WET AREAS:

- Use the Foamstrip and the Pergo Aqua Sealant at the entire perimeter, profiles, pipe cover, ...
- Use the Pergo water resistant skirtings.

For more information about the finishing and the use of the accessories: check the technical data sheet of the accessories, click/scan the Finishing accessories QR-code.

## RE-USE / RECYCLING



CIRCULAR  
FLOORING

- In case of a floating installation, thanks to our click system your floor can be disassembled and reused elsewhere.
- Deliver installation waste or a disassembled floor to a recognized waste collection facility or recycling point.
- For more information about our "RECOVER" program or packaging waste handling, click/scan the Circular flooring QR-code.
- The Pergo packaging is composed of multiple recyclable components. Please check your local or national regulations to optimize this waste sorting and handling.

Last but not least, enjoy your high-quality floor!